EmuElec4 BASIC users manual on ODROID-GO Super

LED Indicators



Front view & controls.
(to be set in START / CONTROLLERS SETTINGS / CONFIGURE A CONTROLLER)

Top view & controls.

Back view.

* Hold Right CTRL & tap PAD Left for screen Dimmer, Right for screen Brighter.

* Press SELECT & START at same time, twice, to exit game.

* Press A button to select game, list, choose, etc.

* PWR button controls -

when Powered OFF - When plugged in (tap), shows battery charging on display.
Press & hold for 2 seconds to turn on.

when Powered ON - Tap to suspend system / wake up system.
Press & hold for 6 seconds to force power off (ONLY when needed!).

* To power down normally - On main systems screen, press SELECT & choose "SHUTDOWN SYSTEM".

* Action buttons for Playstion- A = O circle
B = X cross
X = Triangle
Y = Square

* When charging unit, best to charge ONLY when NOT playing & FULLY powered off.

* Thanks to Hard Kernel for the original pics *